

LOVATO		LOVATO GS	ABB	SOCOMEK	SCHNEIDER
Description	Order Code	Order Code	Order Code	Order Code	Order Code

Three pole switch disconnectors without direct handle

To complete with shaft and handle for door coupling

With direct handle

With direct handle

● With extension and handle included

3P SWITCH DISCONNECTOR 16A	GA016A	7 GS016 A		2200 3000 (16A)	V01 (20A)
				2200 3001 (20A)	VCCF-01 (20A) ●
3P SWITCH DISCONNECTOR 25A	GA025A	7 GS025 A	OT16E3 non modulare	2200 3002	V0
					VCCF-0 ●
3P SWITCH DISCONNECTOR 32A	GA032A	7 GS032 A	OT25E3 non modulare	2200 3003	V1
					VCCF-1 ●
3P SWITCH DISCONNECTOR 40A	GA040A	7 GS040 A	OT32E3 non modulare	2200 3004	V2
					VCCF-2 ●
3P SWITCH DISCONNECTOR 63A	GA063A	7 GS063 MA	OT45E3	2200 3006	V3
					VCCF-3 ●
3P SWITCH DISCONNECTOR 80A	GA080A	7 GS 080 MA	OT63E3	2200 3008	V4
					VCCF-4 ●
3P SWITCH DISCONNECTOR 100A	GA100A	7 GS100 MA	OT100E3	2200 3010	
3P SWITCH DISCONNECTOR 125A	GA125A	7 GS125 MA	OT125E3	2200 3011	V5
					VCCF-5 ●

Three pole switch disconnectors, direct actuator, black handle included.

To complete with shaft and handle for door coupling

Blue handle

Black handle not padlockable

3P SWITCH DISCONNECTOR 16A	GA016A	7 GS016 B		2205 3000 (16A)	
				2205 3001 (20A)	
3P SWITCH DISCONNECTOR 25A	GA025A	7 GS025 B		2205 3002	VVD-0
3P SWITCH DISCONNECTOR 32A	GA032A	7 GS032 B		2205 3003	VVD-1
3P SWITCH DISCONNECTOR 40A	GA040A	7 GS040 B		2205 3004	VVD-2
3P SWITCH DISCONNECTOR 63A	GA063A	7 GS063 MB		2205 3006	VVD-3
3P SWITCH DISCONNECTOR 80A	GA080A	7 GS080 MB		2205 3008	VVD-4
3P SWITCH DISCONNECTOR 100A	GA100A	7 GS100 MB		2200 3010+ 2299 5012	

3P SWITCH DISCONNECTOR 125A	GA125A	7 GS125 MB		2200 3011+ 2299 5012	
-----------------------------	--------	------------	--	----------------------	--

Three pole switch disconnectors, direct actuator, red/yellow handle included.

To complete with shaft and handle for door coupling

	Black handle		Grey front plate	Blue handle	Red/Yellow handle Padlockable
3P SWITCH DISCONNECTOR 16A	GA016A	7 GS016 BRY		2205 3000 (16A) 2205 3001 (20A)	
3P SWITCH DISCONNECTOR 25A	GA025A	7 GS025 BRY	OT16E3 non modulare	2205 3002	VVE-0
3P SWITCH DISCONNECTOR 32A	GA032A	7 GS032 BRY	OT25E3 non modulare	2205 3003	VVE-1
3P SWITCH DISCONNECTOR 40A	GA040A	7 GS040 BRY	OT32E3 non modulare	2205 3004	VVE-2
3P SWITCH DISCONNECTOR 63A	GA063A	7 GS063 MBRY	OT45E3	2205 3006	VVE-3
3P SWITCH DISCONNECTOR 80A	GA080A	7 GS080 MBRY	OT63E3	2205 3008	VVE-4
3P SWITCH DISCONNECTOR 100A	GA100A	7 GS100 MBRY	OT100E3	2200 3010+ 2299 5012	
3P SWITCH DISCONNECTOR 125A	GA125A	7 GS125 MBRY	OT125E3	2200 3011+ 2299 5012	

Three pole switch disconnectors for door mounting.

Body and extension included. To complete with handle only

				Buy kit 2299 3309	Handle included
3P SWITCH DISCONNECTOR 16A	GA016C	7 GS016 C		2200 3000 (16A) 2200 3001 (20A)	VCD-01 diam. 22,5▲ (20A) VCF-01 screw fixing ▲ (20A)
3P SWITCH DISCONNECTOR 25A	GA025C	7 GS025 C	OT16ET3	2200 3002	VCD-0 diam. 22,5 ▲ VCF-0 screw fixing ▲
3P SWITCH DISCONNECTOR 32A	GA032C	7 GS032 C	OT25ET3	2200 3003	VCD-1 diam. 22,5 ▲ VCF-1 screw fixing ▲
3P SWITCH DISCONNECTOR 40A	GA040C	7 GS040 C	OT32ET3	2200 3004	VCD-2 diam. 22,5 ▲ VCF-2 screw fixing ▲
3P SWITCH DISCONNECTOR 63A	GA063C	7 GS063 C	OT45ET3	2200 3006	VCF-3 screw fixing ▲
3P SWITCH DISCONNECTOR 80A	GA080C		OT63ET3	2200 3008	VCF-4 screw fixing ▲
3P SWITCH DISCONNECTOR 100A	GA100C		OT100ET3	2200 3010	
3P SWITCH DISCONNECTOR 125A	GA125C		OT125ET3	2200 3011	VCF-5 screw fixing ▲

ADD-ON BLOCKS AND ACCESSORIES

Fourth pole, simultaneous closing of all disconnector poles

Door coupling version

3P SWITCH DISCONNECTOR 16A	GAX42040A	7GSP016AB		2200 1000	VZ-01 (20A)
3P SWITCH DISCONNECTOR 25A		7GSP025AB	OTPS32EP	2200 1002	VZ-0

3P SWITCH DISCONNECTOR 32A	GAX42040A	7GSP032AB	OTPS32EP	2200 1003	VZ-1
3P SWITCH DISCONNECTOR 40A		7GSP040AB	OTPS32EP	2200 1004	VZ-2
3P SWITCH DISCONNECTOR 63A	GAX42063A	7GSP063MAB	OTPS63EP	2200 1006	VZ-3
3P SWITCH DISCONNECTOR 80A	GAX42080A	7GSP080MAB	OTPS63EP	2200 1008	VZ-4
3P SWITCH DISCONNECTOR 100A	GAX42100A	7GSP100MAB	OTPS125EP	2200 1010	
3P SWITCH DISCONNECTOR 125A	GAX42125A	7GSP125MAB	OTPS125EP	2200 1011	

Door mounting verion

3P SWITCH DISCONNECTOR 16A	GAX42040C	7GSP016C		2200 1000	VZ-01 (20A)
3P SWITCH DISCONNECTOR 25A		7GSP025C	OTPS32ED	2200 1002	VZ-0
3P SWITCH DISCONNECTOR 32A		7GSP032C	OTPS32ED	2200 1003	VZ-1
3P SWITCH DISCONNECTOR 40A		7GSP040C	OTPS32ED	2200 1004	VZ-2
3P SWITCH DISCONNECTOR 63A	GAX42063C	7GSP063C	OTPS63ED	2200 1006	VZ-3
3P SWITCH DISCONNECTOR 80A	GAX42080C		OTPS63ED	2200 1008	VZ-4
3P SWITCH DISCONNECTOR 100A	GAX42100C		OTPS125ED	2200 1010	
3P SWITCH DISCONNECTOR 125A	GAX42125C		OTPS125ED	2200 1011	

Fourth pole, early-make closing respect to disconnecter poles

Door coupling version

3P SWITCH DISCONNECTOR 16A	GAX41040A				VZ-11
3P SWITCH DISCONNECTOR 25A			OTPL32EP		VZ-11
3P SWITCH DISCONNECTOR 32A			OTPL32EP		VZ-11
3P SWITCH DISCONNECTOR 40A			OTPL32EP		VZ-11
3P SWITCH DISCONNECTOR 63A	GAX41125A		OTPL63EP		VZ-12
3P SWITCH DISCONNECTOR 80A			OTPL63EP		VZ-12
3P SWITCH DISCONNECTOR 100A			OTPL125EP		
3P SWITCH DISCONNECTOR 125A			OTPL125EP		VZ-13

Fourth pole, early-make closing respect to disconnecter poles

Door mounting verion

3P SWITCH DISCONNECTOR 16A	GAX41040C				VZ-11
3P SWITCH DISCONNECTOR 25A			OTPL32ED		VZ-11
3P SWITCH DISCONNECTOR 32A			OTPL32ED		VZ-11
3P SWITCH DISCONNECTOR 40A			OTPL32ED		VZ-11
3P SWITCH DISCONNECTOR 63A	GAX41125C		OTPL63ED		VZ-12
3P SWITCH DISCONNECTOR 80A			OTPL63ED		VZ-12
3P SWITCH DISCONNECTOR 100A			OTPL125ED		
3P SWITCH DISCONNECTOR 125A			OTPL125ED		VZ-13

ADD-ON BLOCKS AND ACCESSORIES

Auxiliari contacts

1 NO+1NC DOOR COUPLING	GAX1011A	7GSXAB	OA2G11	2299 0001	VZ-20
1 NO+1NC DOOR MOUNTING	GAX1011C	7GSXC	OA1G10 / OA1G01	2299 0001	VZ-20

Door coupling handle extension shafts

45MM LONG FOR USE IN GAZ16-40A ENCLOSURE					
55 MM LONG	GAX7055	7GSS055			
70 MM LONG	GAX7070	7GSS070			
90 MM LONG	GAX7090	7GSS090	OXS5x85		
150 MM LONG	GAX7150	7GSS150	OXS5x160	1407 0515	
200 MM LONG	GAX7200	7GSS200	OXS5x180	1407 0520	
300 MM LONG	GAX7300	7GSS300	OXS5x330	1407 0532 (320mm)	VZ-17 (12-40A) VZ-18 (125A)

Neutral terminal

FOR SWITCH 16-40A DOOR COUPLING	GAX31A	7GSNAB	OTPN32EP	2200 5005	
FOR SWITCH 63-125A DOOR COUPLING	GAX32A	7GSNC	OTPN63EP (up to 80A)	2200 5009 (up to 80A)	
			OTPN125EP	2200 5011	
FOR SWITCH 16-40A DOOR MOUNTING	GAX31C	7GSNMAB	OTPN32ED	2200 5005	
FOR SWITCH 63-125A DOOR MOUNTING	GAX32C		OTPN63ED (up to 80A)	2200 5009 (up to 80A)	
			OTPN125ED	2200 5011	

Earth pole

FOR SWITCH 16-40A DOOR COUPLING	GAX33A	7GSGAB	OTPE32EP	2200 9005	VZ14 (12-40A)
FOR SWITCH 63-125A DOOR COUPLING	GAX34A	7GSGC	OTPE63EP (up to 80A)	2200 9009 (up to 80A)	VZ15 (63-80A)
			OTPE125EP	2200 9011	VZ16 (125A)
FOR SWITCH 16-40A DOOR MOUNTING	GAX33C	7GSGMAB	OTPE32ED	2200 9005	VZ14 (12-40A)
FOR SWITCH 63-125A DOOR MOUNTING	GAX34C		OTPE63ED (up to 80A)	2200 9009 (up to 80A)	VZ15 (63-80A)
			OTPE125ED	2200 9011	VZ16 (125A)

Yellow red door coupling handle. Padlockable, IP65

SCREW FIXING. ECONOMIC HANDLE	GAX61	7GSH3		2299 5012 (blue direct)	
SCREW FIXING. SELECTOR HANDLE	GAX62		OHY2RJ (only for door mounting)		KCF-1PZ (12-40A) KCF-2PZ (63-80A) KCF-3PZ (125A)
RING FIXING. ALL MOUNTING	GAX63		OHY2AJ1	1474 1111 (up to 80A) 1484 1111 (100-125A)	KCD-1PZ (12-40A)
			OHY2AJ	1474 1111 (up to 80A)	
RING FIXING UL VERSION. ALL MOUNTING	GAX64		OHY2PJ (only for door mounting up to 40A)	1484 1111 (100-125A)	
SCREW FIXING. PISTOL GRIP FOR DOOR COUPLING VERSION	GAX65		OHY45J5		

Black door coupling handle. Padlockable, IP65

SCREW FIXING. ECONOMIC HANDLE	GAX61B	7GSH2		2299 5012 (blue direct)	
SCREW FIXING. SELECTOR HANDLE	GAX62B		OHB2RJ (only for door mounting)		KAF-1PZ (12-40A) KAF-2PZ (63-80A) KAF-3PZ (125A)
RING FIXING. ALL MOUNTING	GAX63B		OHB2AJ1	1473 1111 (up to 80A) 1483 1111 (100-125A)	KAD-1PZ (12-40A)
RING FIXING UL VERSION. ALL MOUNTING	GAX64B		OHB2AJ OHB2PJ (only for door mounting up to 40A)	1473 1111 (up to 80A) 1483 1111 (100-125A)	
SCREW FIXING. PISTOL GRIP FOR DOOR COUPLING VERSION	GAX65B		OHB45J5		

Set of 2 terminal covers

Three-pole

FOR SWITCH 16-40A	GAX83	7GSTS3	OTS32T3	2294 3005	VZ-8 (12-40A)
FOR SWITCH 63-125A	GAX84	7GSTS4	OTS63T3 (up to 80A) OTS125T3	2294 3009 (up to 80A) 2294 3016	VZ-9 (63-80A) VZ-10 (125A)

One pole

FOR SWITCH 16-40A	GAX81	7GSTS1	OTS32T1	2294 1005	VZ-26 (12-40A)
FOR SWITCH 63-125A	GAX82	7GSTS2	OTS63T1 (up to 80A) OTS125T1	2294 1009 (up to 80A) 2294 1011	VZ-27 (63-80A) VZ-28 (125A)

THREE POLE SWITCH DISCONNECTORS IN ENCLOSURE

With yellow/red handle

			PG / M cable entry	PG / M cable entry	
3P SWITCH DISCONNECTOR 16A	GAZ016	7GSZ016RY	OTP16BA3P / OTP16BA3M	2415 9501 (20A) / 2415 9401 (20A)	VCF-01GE
3P SWITCH DISCONNECTOR 25A	GAZ025	7GSZ025RY	OTP25BA3P / OTP25BA3M	2415 9502 / 2415 9402	VCF-1GE
3P SWITCH DISCONNECTOR 32A	GAZ032	7GSZ032RY	OTP32BA3P / OTP32BA3M	2415 9503 / 2415 9403	VCF-2GE
3P SWITCH DISCONNECTOR 40A	GAZ040	7GSZ040RY	OTP45BA3P / OTP45BA3M (45A)	2415 9504 / 2415 9404	VCF-3GE (50A)
3P SWITCH DISCONNECTOR 63A	GAZ063	7GSZ063RY	OTP63BA3P / OTP63BA3M	2415 9506 / 2415 9406	VCF-4GE
3P SWITCH DISCONNECTOR 80A	GAZ080	7GSZ080RY	OTP80BA3B / OTP80BA3M		
3P SWITCH DISCONNECTOR 100A	GAZ100	7GSZ100RY			VCF-5GE
3P SWITCH DISCONNECTOR 125A	GAZ125	7GSZ125RY	OTP125BA3B / OTP125BA3M		VCF-6GE (140A)

With black handle

			PG / M cable entry		
3P SWITCH DISCONNECTOR 16A	GAZ016B	7GSZ016	OTP16B3P / OTP16B3M		VBF-01GE
3P SWITCH DISCONNECTOR 25A	GAZ025B	7GSZ025	OTP25B3P / OTP25B3M		VBF-1GE
3P SWITCH DISCONNECTOR 32A	GAZ032B	7GSZ032	OTP32B3P / OTP32BM		VBF-2GE
3P SWITCH DISCONNECTOR 40A	GAZ040B	7GSZ040	OTP45B3P / OTP45B3M (45A)		VBF-3GE (50A)
3P SWITCH DISCONNECTOR 63A	GAZ063B	7GSZ063	OTP63B3P / OTP63B3M		VBF-4GE
3P SWITCH DISCONNECTOR 80A	GAZ080B	7GSZ080	OTP80B3B / OTP80B3M		

3P SWITCH DISCONNECTOR 100A	GAZ100B	7GSZ100			VBF-5GE
3P SWITCH DISCONNECTOR 125A	GAZ125B	7GSZ125	OTP125B3B / OTP125B3M		VBF-6GE (140A)

EMPTY ENCLOSURES

With yellow/red handle

FOR SWITCH 16-40A DOOR COUPLING	GAZ1	7GSZRY			VCFX-GE1 (12-40A)
FOR SWITCH 63-125A DOOR COUPLING	GAZ3				VCFX-GE4 (63-80A)
					VCFX-GE2 (125A)

With black handle

FOR SWITCH 16-40A DOOR COUPLING	GAZ1B	7GSZ			VBFX-GE1 (12-40A)
FOR SWITCH 63-125A DOOR COUPLING	GAZ3B				VBFX-GE4 (63-80A)
					VBFX-GE2 (125A)

▲ PER AVERE LA MANIGLIA NERA LUCHET. SOSTITUIRE LA LETTERA C CON LA B (AD ES. VCD-01 DIVENTA VBD-01)